

Aquapel (Clarity One) Solution Field Application

Step 1: Clean Glass

Thoroughly clean the glass. It must be totally free of dirt, butyl, caulk, etc., prior to the application of solution.

Step 2: Apply Solution

To apply, hold the applicator with your thumb and fingers with the pad down and level on the glass.

Squeeze the wings together until a popping sound is heard and the liquid is released onto the pad.

Use immediately

Utilize the applicator to apply the solution to the entire outside glass surface. Avoid the vinyl parts of the sash



Field Applicator Item # UF003100

Step 3: Dry Glass Completely

Wipe the glass with a clean dry paper towel immediately after the solution has been applied. Make sure the entire glass surface is completely cleaned. Dispose of applicator and paper towel.

Failure to clean the entire surface and wipe the glass immediately may cause hazing that requires additional buffing with a clean dry paper towel.

Note

Opened applicators must be used immediately. Partially used applicators cannot be stored and used at a later time.